

Engine Mechanical System

| | |
|--|-------|
| ENGINE (KJ2.9 TCI DOHC DIESEL-COMMON RAIL SYSTEM)..... | EM- 2 |
| LUBIRICATION SYSTEM | EM-52 |
| COOLING SYSTEM | EM-59 |
| INTAKE AND EXHAUST SYSTEM | EM-65 |

ENGINE (KJ2.9 TCI DOHC DIESEL-COMMON RAIL SYSTEM)


| | |
|--|---------------|
| SPECIAL SERVICE TOOLS | EMa-2 |
| SYMPTOM-RELATED DIAGNOSTIC PROCEDURE | EMa-4 |
| SPECIFICATION | EMa-7 |
| ON-VEHICLE SERVICE PROCEDURES..... | EMa-8 |
| REMOVAL AND REPLACEMENT PROCEDURES..... | EMa-16 |
| DISASSEMBLY, INSPECTION AND REASSEMBLY PROCEDURE..... | EMa-24 |

SPECIAL SERVICE TOOLS

Engine Special service tools

0K130 990 007


Engine stand



Used to disassemble and assemble engine.

0K410 101 004


Hanger, engine stand



Used to disassemble and assemble engine.

0K993 120 004


Pivot, valve spring lifter



Used to remove and install valve.

0K710 120 004


Installer, valve seal



Used to install valve seal.

0K130 160 010

Centering tool, clutch disc



Used to install clutch disc and clutch cover.

0K552 111 001


Holder, camshaft pulley



Used to install camshaft pulley.

0K552 131 002


Adapter, compression gauge




Used to measure compression pressure.

0K993 120 001


Arm, valve spring lifter




Used to remove and install valve.

0K993 120 006**Remover, valve seal**

Used to remove valve seal.

0K590 111 001**Ring gear brake set**

Used to prevent engine rotation.

0K130 111 004**Holder, coupling flange**

Used to remove camshaft gear.

SYMPTOM-RELATED DIAGNOSTIC PROCEDURE

Engine Diagnostic chart

| Problem | Possible Cause | Action to be taken |
|---|--|---|
| Insufficient power smoke generation | Insufficient compression caused by: <ol style="list-style-type: none"> 1. Contaminated air cleaner element 2. Loose hose connection between compressor and intercooler 3. Leakage from intake manifold 4. Leakage from exhaust manifold 5. Leakage from turbocharger mounting flange 6. Interference between turbocharger compressor turbine and case 7. Blocked duct between air cleaner and turbocharger compressor 8. Blocked duct between compressor and intake manifold 9. Interference between intake and exhaust manifolds 10. Leakage from valve seat 11. Seized valve stem 12. Weak or broken valve spring 13. Failed cylinder head gasket 14. Cracked or distorted cylinder head 15. Sticking, damaged, or worn piston ring 16. Cracked or worn piston Malfunction of fuel system Slipping clutch Wrong tire size Restricted exhaust system system | |
| Excessive oil consumption | Abnormal engine oil viscosity Leakage from turbocharger compressor (adhesion of oil to housing or wheel) Leakage turbocharger turbine Worn or sticking piston ring or groove Worn piston or cylinder Bad valve seal Worn valve stem or guide | Replace Repair Repair Replace Repair or replace Replace Replace |
| Engine cranks normally, but does not start | Malfunction of fuel system Malfunction of electrical system Restricted exhaust system Timing belt and/or related parts Low compression Camshaft worn | Replace |
| Blue smoke out of exhaust | Usually caused by oil burning in the combustion chamber from: worn rings, worn valve guides, worn valve seals or failed cylinder head gasket Contaminated air cleaner element Loose hose connection between compressor and intercooler Leakage from intake manifold Blocked oil filter Blocked duct between air cleaner and turbocharger compressor Leakage from turbocharger compressor | Replace Tighten Repair Replace Repair Repair |

| Problem | Possible Cause | Action to be taken |
|--|---|---|
| White smoke out of exhaust | Usually caused by water vapor, which is a normal by product of combustion on cold days. Excessive white smoke with engine warmed up could be caused by a failed cylinder head or intake gasket, could also be cracked block, cylinder head or intake manifold. | None required Repair or replace |
| Black smoke out of exhaust | Malfunction of fuel system Malfunction of emission system | |
| Abnormal combustion | Sticking or burned valve Weak or broken valve spring Carbon accumulation in combustion chamber | Replace Replace Eliminate the carbon |
| Poor idling | Malfunction of fuel system Malfunction of emission system Uneven cylinder compression Poor valve to valve seat contact Broken valve spring Failed cylinder head gasket | Repair Repair or replace Repair Replace |
| Turbocharger noise | Contaminated air cleaner element Foreign material in intake duct or compressor housing Foreign material between intake manifold and compressor Foreign material in engine exhaust system Carbon deposit on turbine housing Interference between turbocharger rotating parts Loose connecting parts of intake and exhaust system | Replace Clean Clean Clean Clean Repair or replace Tighten |
| Engine knocks when hot and at idle | Loose or worn accessory drive belt/tensioner Improper oil viscosity Excessive piston pin clearance Connecting rod alignment Insufficient piston to bore clearance Faulty timing belt tensioner or guide Loose damper pulley | Replace if necessary Install proper oil viscosity for expected temperature Install new piston pin and/or connecting rod Check and replace Hone and fit new pistons Replace Tighten or replace |
| Slight noise at idle, becomes louder as engine speed is increased | Valve spring clicking on cap, off square or broken Excessive stem to guide clearance Excessive valve seat runout Holed exhaust pipe | Repair or replace Repair Repair Replace |
| Engine knocks when cold | Excessive piston to wall clearance Loose or broken damper pulley | Replace Tighten or replace |
| Knock increase with torque | Excessive piston to bore clearance Bent connecting rod | Replace piston Replace |
| Engine has heavy knock when hot and torque is applied | Broken damper pulley Accessory belts too tight or damaged Belt tensioner damaged Flywheel cracked or loose clutch plate Excessive main bearing clearance Excessive rod bearing clearance | Replace Adjust or replace belt Replace Replace flywheel or clutch plate Repair Repair |

| Problem | Possible Cause | Action to be taken |
|---|---|--|
| Engine has light knock when hot and under light load conditions | Improper timing Piston pin and/or connecting rod Poor quality fuel Exhaust leak at manifold Excessive rod bearing clearance | Check timing Replace Replace Tighten or replace Repair |
| Engine knocks on initial start up and knock lasts only a few seconds | Improper oil viscosity | Install proper oil viscosity for expected temperature |
| Interference of turbocharger, poor rotation | Damaged compressor blades due to external cause Interference of turbine and compressor blades with housing Excessive deposit on compressor housing or wheel Excessive carbon deposit on the back of turbine blade Burn out of center housing | Repair or replace Repair or replace Clean or repair Clean or repair Replace |
| Leakage from turbocharger turbine shaft | Excessive initial oil applying Blocked crankcase breather Obstacle in turbocharger oil drain line Burn out of center housing Wear on turbocharger bearing, bearing bore or shaft journal Excessive crankcase oil | Burn it normally Repair Clean and repair Clean and replace Repair or replace Correct oil amount |
| Leakage from turbocharger compressor | Contaminated air cleaner element Blocked duct between compressor and air cleaner Loose compressor and intake system connecting duct Leakage from intake manifold Obstacle in turbocharger oil drain line Blocked blowby passage in crankcase Worn or damaged compressor blades Wear on turbocharger bearing bore, bearing or shaft journal | Replace Repair Tighten Repair Repair or replace Repair Clean or replace Replace |
| Wear on turbocharger bearing, bore or shaft journal | Contaminated oil Insufficient oil supply Obstacle in turbocharger oil supply line Plugged oil filter Poor oil pump operation | Replace Check Check and repair Replace Check and repair |

SPECIFICATION


Engine Specification

| Engine model | | | KJ 2.9TCI DOHC-COMMON RAIL SYSTEM |
|---|------------------------------------|--------|-----------------------------------|
| Item | | | |
| Type | | | Diesel, 4-Cycles |
| Number of cylinders | | | 4-Cylinder in-line |
| Combustion chamber | | | Re-entrant |
| Displacement | cu. in (cc) | | 177 (2902) |
| Bore and stroke | in (mm) | | 3.82 X 3.85 (97.1 X 98) |
| Compression ratio | | | 19.3 |
| Compression pressure | psi (kPa, kg/cm ²)-rpm | | 426.6 (2943, 30) - 200 |
| Valve timing | Intake | Open | BTDC 26° |
| | | Closed | ABDC 50° |
| | Exhaust | Open | BBDC 50° |
| | | Closed | ATDC 29° |
| Valve clearance(cold engine) in (mm) | Intake | | 0 : Maintenance-free |
| | Exhaust | | 0 : Maintenance-free |
| Idle speed | rpm | | 800 ±100 |
| Injection order | | | 1-3-4-2 |

ON-VEHICLE SERVICE PROCEDURE

Engine oil

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for 5 minutes.
4. Remove the oil level gauge and check the oil level and condition.



AGX010A022


5. Add or replace oil if necessary.

Engine coolant Coolant level

⚠ WARNING

- A) NEVER REMOVE THE RADIATOR CAP WHILE THE ENGINE IS HOT.
- B) WRAP A THICK CLOTH AROUND THE CAP WHEN REMOVING IT.

1. Verify that the coolant level is near the radiator filler neck.
2. Check that the level in the coolant reservoir is between the "Full" and "Low" marks.



AV2A10020

3. Add coolant if necessary.


Coolant quality

1. Verify that there is no build up of rust or scale around the radiator cap or radiator filler neck.
2. Verify that the coolant is free of oil.
3. Replace the coolant if necessary.

Drive belt


Inspection

1. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.
3. Verify that “ ” mark of auto-tensioner align “ ” mark. If two marks align as shown ①, the tension of auto-tensioner is good. If not align as shown ②, re-install the auto-tensioner or replace the drive belt.



AV2A10B001

4. Check the A/C drive belt deflection by applying moderate pressure (22 lb, 98 N, 10 kg) midway



AV2A10B002

between the pulleys.


Caution

- a) Measure the belt deflection between the pulleys.
- b) Consider the belt as a new one if it has been used on a running engine for less than five minutes.
- c) Check the belt deflection when the engine is cold or at least 30 minutes after the engine is stopped.

A/C belt deflection:

New one: 0.28~0.35 in (7~9 mm)
Used one: 0.35~0.43 in (9~11 mm)

Adjustment



AN9010018-1

1. Loosen the idler pulley mounting bolt.
2. Adjust the belt deflection by turning the adjusting bolt.

Deflection (When applying 22 lb, 98 N, 10 kg)

New one: 0.28~0.35 in (7~9 mm)

Used one: 0.35~0.43 in (9~11 mm)


3. After making the adjustment, tighten the idler pulley mounting bolt.

Tightening torque:

28~38 lb-ft (37~52N•m, 3.8~5.3 kg-m)

Replacement

1. Raise the vehicle and support it with safety stands.
2. Remove the RH side wheel.
3. Loosen the idle pulley mounting bolt.
4. Remove the A/C drive belt.
5. Lower the auto tensioner with spanner and then remove the drive belt.




AV2A10B038

6. Lower the auto tensioner with spanner and then install the drive belt.
7. Install the A/C drive belt.
8. Check the A/C drive belt deflection.


Timing belt

Removal


1. Raise vehicle and support it with safety stands.
2. Remove the radiator upper hose.
3. Remove the fuel filter hoses still connected.
4. Remove the No.3 engine mounting rubber.



5. Remove the No.3 engine mounting bracket.




6. Remove the RH side wheel.
7. Remove the A/C drive belt.
8. Remove the drive belt.
9. Remove the auto tensioner.
10. Remove the water pump pulley.
11. Remove the crankshaft pulley.
12. Remove the upper timing belt cover.
13. Remove the lower timing belt cover.
14. Rotate crankshaft and align timing mark on timing belt pulley with timing mark on engine block.



15. Remove the auto tensioner.
16. Remove the timing belt.

Replacement

1. Check that timing mark on timing belt pulley, camshaft pulley and high pressure pump pulley is aligned with timing mark on engine.



2. Install the timing belt.


- 1) The timing belt is installed in sequence crank shaft pulley, idler No.2, high pressure pump pulley, idler No.1 and camshaft pulley.

* Notice

- a) The auto-tensioner must be mounted onto the engine after the timing belt is installed.
- b) Keep the tension of timing belt when install timing belt.

3. Install the auto-tensioner.

- 1) Install the auto-tensioner as shown illust. The dowel pin has to be located between the tensioner fork (back plate).



- 2) Pretighten the auto-tensioner.

Tightening torque:

2.9lb-ft (3.9N•m , 0.4kg-m)


* Notice

- a) Oil must not get in contact with the tensioner. The tensioner has to be replaced by a new one, if it is oily.
- b) The positions of the pointer, the back plate and the special washer are in accordance to the illust.

4. Check again if the alignment marks of camshafts, crankshaft and high pressure pump are aligned with the marks on the timing case.

5. Adjust the auto-tensioner, and then tighten it.


- 1) Align the pointer to the back plate by rotating the special washer in counter-clockwise using the hexagon wrench as shown illust.



- 2) Tighten the auto-tensioner lock bolt with holding the special washer by the hexagon wrench when the pointer is aligned with the back plate.

Tightening torque :

17.4lb-ft (23.5N•m , 2.4kg-m)




- 3) Remove the hexagon wrench.

* Notice

If the pointer can not be aligned with the back plate, then a new belt has to be used.

6. Rotate the crankshaft two full revolutions in clockwise to align the TDC mark.
7. Check again if the alignment marks of camshafts, crankshaft and high pressure pump are aligned with the marks on the timing case.
8. Check the alignment of the pointer and back plate.



BV2A10B007

Allowance misalignment : $\pm 5^\circ$

9. If the misalignment between pointer and back plate is bigger than $\pm 5^\circ$, repeat step 4~8.
10. Install the upper and lower timing belt cover.

Tightening torque:

5.1~7.2 lb-ft (6.9~9.8 N•m, 70~100 kg-cm)

11. Install the crankshaft pulley.

Tightening torque:

253~289 lb-ft (343~392 N•m, 35~40 kg-m)

12. Install the water pump pulley.

Tightening torque:

13.0~20.9 lb-ft (17.6~28.4 N•m, 1.8~2.9 kg-m)

13. Install the auto tensioner.

Tightening torque:

13.0~20.9 lb-ft (17.6~28.4 N•m, 1.8~2.9 kg-m)

14. Install the drive belt and A/C drive belt.

15. Install the RH side wheel.

Tightening torque:

65~79 lb-ft (88~108 N•m, 9.0~11.0 kg-m)

16. Install the No.3 engine mounting bracket.

Tightening torque:


26.7~39.8 lb-ft (36.2~53.9 N•m, 3.7~5.5 kg-m)

17. Install the No.3 engine mounting rubber.

Tightening torque:

Nut: 49.1~68.7 lb-ft (66.7~93.1 N•m, 6.8~9.5 kg-m)

Bolt: 62.9~86.0 lb-ft (85.3~116.7 N•m, 8.7~11.9 kg-m)



AV2A10B039A

18. Install the fuel filter.
19. Install the radiator hose.
20. Fill engine coolant with specified type and amount.
21. Start engine and then check for leaks.

Compression pressure Inspection


1. Warm up the engine upto the normal operating temperature, then stop the engine and disconnect the connector of fuel cut solenoid.
2. Remove all injection pipes, nozzles and washers.
3. Attach the **SST** to the nozzle hole.
4. Measure the compression pressure during cranking.

| Engine model | | KJ2.9 TCI DOHC COMMON RAIL SYSTEM |
|--|--------|--------------------------------------|
| Item | | |
| Compression pressure psi (kPa, kg/cm ²)-rpm | Normal | 426.6(2943, 30)-200 |
| | Limit | 383.9(2649, 27)-200 |
| Cylinder-to-cylinder pressure difference psi (kPa, kg/cm ²) | | below 42.7(294,3.0) |

5. Do above step 3~4 again for each cylinder.
6. If the measure value is below the limit, consider it as abrasion or damage of piston and piston ring, misalignment of valve, damage of gasket, and etc..

Ladder frame and balance shaft Removal


1. Remove oil pan.
2. Adjust the V groove TDC mark on the outside of pulley to the TDC mark "T" on the timing cover, by rotating the crank shaft pulley.



AV2A10B031

3. For timing check, loosen the 3 balance gear cover bolts on the back of ladder frame and check the balance gear assembly mark.


*** Notice**
To prevent the balance shaft from being falled out, tighten the 1 of 3 balance gear cover bolts by hand into the thrust plate center.



AV2A10B006


4. When reassembling after checking the balance gear assembly mark, mark the chain link with marking pen that is matched with Ø0.12 in (3 mm) round TDC mark to adjust the timing.

*** Notice**
Disregard the 2 yellow points on the chain link because it is only available for engine assembly.




5. Loosen balance sprocket bolt.

*** Notice**
 Insert the 0.2 in (5 mm) urethane rubber between balance gear to prevent the balance shaft from rotating and the balance gear from damaging.



6. When disassembling the balance sprocket, hold the balance sprocket by one hand with pushing the thrust plate slightly then the balance separates from the neck of balance shaft.
7. When disassembling ladder frame, separate the oil feeding pipe from the oil pump by loosening the oil feeding pipe bolt.



8. Loosen the ladder frame fastener bolt. Remove ladder frame.

Replacement

1. Measure end play of balance shaft.

End play: 0.0039~0.0098 in (0.1~0.25 mm)

2. Install the balance shaft and thrust plate assembly into the ladder frame.

*** Notice**

To prevent the balance shaft from being falled out, tighten the 1 of 3 balance gear cover bolts by hand into the thrust plate center.


3. Install the ladder frame into block. Check the dowel pin of ladder frame is matched with lower surface of block and insert the oil level gauge into the ladder frame hole.

Tightening torque (ladder frame bolt):
32.5 lb-ft (44 N·m, 4.5 kg-m)

4. Install crankshaft sprocket, oil pump sprocket, guide and chain tensioner.
5. Adjust balance shaft sprocket position mark with chain link mark, and then insert the sprocket into the neck of balance shaft.


*** Notice**

For smooth operation, pull the thrust plate out and hold, and then push the sprocket into the balance shaft.



AV2A10B032

6. Push the end of chain tensioner plunger utmost and then install the chain tensioner lever between chain and chain tensioner.



AV2A10B027A

7. Tighten balance sprocket bolt.

*** Notice**

Insert the 0.2 in (5 mm) urethane rubber between balance gear to prevent the balance shaft from rotating and the balance gear from damaging.

Tightening torque:

Mark 10T: 50.6 lb-ft (68.6 N•m, 7 kg-m)


Mark 8T: 43.4 lb-ft (58.8 N•m, 6 kg-m)

8. Rotate the crankshaft pulley 2 times and make the chain 1 rotating fully, check the adjustment between crankshaft pulley TDC mark and timing cover TDC mark after checking the balance gear assembly mark. If not, readjustment is needed.

*** Notice**

The chain link mark position is only efficient to assembly, but it is not matched after 2 rotation of crankshaft pulley.

Timing check is only possible through the balance shaft gear.




AV2A10B081

9. Loosen the bolt on the thrust plate, and install the gear cover and tighten 3 bolts.


Tightening torque:

16.6 lb-ft (23 N•m, 2.3 kg-m)



AV2A10B035

10. Install the oil feeding pipe into the ladder frame, oil pump and block and then tighten bolts.




AV2A10B036

11. Install the oil pan.
12. Fill engine oil with specified type and amount.
13. Start engine and then check for leaks.

REMOVAL AND REPLACEMENT PROCEDURES


Engine Removal

1. Disconnect negative and positive battery cable.
2. Raise and properly support vehicle.
3. Drain engine coolant.
4. Remove the battery and battery tray.
5. Remove the flash air duct air cleaner assembly and air cleaner bracket.
6. Disconnect the RH side wiper motor connector.
7. Remove the coolant reservoir hose from the thermostat housing.
8. Disconnect the two ground connectors from the fuse box.
9. Remove the ground from the body side.




AV2A10B042

10. Disconnect the five connectors.




AV2A10B043

11. Remove the U-clip.
12. Remove the nut and washer from the auto transaxle linkage.



AV2A42118

13. Disconnect the heater hose from thermostat housing.
14. Disconnect the two vacuum hoses and water temperature sensor connector.



AV2A10B044


15. Remove the auto transaxle filter tube assembly.
16. Disconnect the brake vacuum hose from the alternator

17. Remove the fuel hose from the sedimenter.
18. Remove the two hoses from power steering reserve tank.

Caution


After removing the power steering line, plug the power steering line to avoid fluid leakage.

19. Remove power steering fluid pipe from the power steering pump.
20. Remove the heater hose.



AV2A10B046


21. Disconnect the two ATF cooler hoses.



AV2A42120

22. Remove both front wheels.
23. Remove the drive belt.
24. Disconnect the magnetic clutch connector.
25. Remove A/C compressor with hoses still connected.

26. Position A/C compressor away from engine and affix it with wire.




BSX010A060

27. Remove exhaust manifold.
28. Remove both right and left tie rod ends from steering knuckles by removing a cotter pin and a nut each.
29. Remove stabilizer bracket and then remove control link from stabilizer.
30. Remove control link from knuckle.

Caution

Be careful not to damage the ball joint dust boot.

31. Remove pinch bolt and nut from both right and left knuckle. Separate lower arm from knuckle.




AV2A42124

32. Remove joint shaft support bracket from engine block(three bolts).


Caution

- a) *Seperate the front wheel driveshaft and joint from the transaxle gradually. If it is suddenly yanked out of transaxle, the differential oil seal may be damaged.*
- b) *After removing the front wheel driveshaft, support the front wheel driveshaft with wire to prevent the driveshaft from damaging the tripod joint bearing and boot.*




BSX041010

33. Gently pry both driveshafts from auto transaxle.



AV2050010

34. Install suitable tool to prevent side gear from becoming misaligned.




Suitable tool

BSX042114

35. Remove intermediate shaft bolt.


36. Remove A/C hose bracket bolt from subframe.



AV2A10B047


37. Remove No.3 and No.4 engine mounting.

38. Support auto transaxle, engine and subframe with a suitable floor jack.




AV2A10026

39. Remove four subframe nuts and four tension rod, nut and then remove subframe.




AV2A42123

40. Slowly lower engine, auto transaxle and subframe.
41. Remove three No.1 engine mounting-to-subframe bolts.




AV2A10B048

42. Remove four No.2 engine mounting bolts and then remove No.2 engine mounting from auto transaxle and subframe.




AV2A10B049

43. Remove starter.
44. Remove under cover assembly.



AV2A10B050

45. Remove six drive plate-to-torque converter mounting nuts. Rotate engine at crank pulley to gain access to all six nuts.



AV2A10B051

46. Remove converter housing bolts.
47. Gently separate transaxle from engine.

Replacement

1. Install auto transaxle to engine and then install converter housing bolts.

Tightening torque:


M19: 47.0~65.8 lb-ft (63.7~89.2 N•m, 6.5~9.1 kg-m)

M17: 27.4~38.3 lb-ft (37.2~51.9 N•m, 3.8~5.3 kg-m)

2. Install six drive plate-to-torque converter mounting nuts. Rotate engine at crank pulley to gain access to all nuts.

Tightening torque:

25.3~36.1 lb-ft (34.3~49.0 N•m, 3.5~5.0 kg-m)




AV2A10B051

3. Install under cover assembly.
4. Install starter.
5. Install No.2 engine mounting.

Tightening torque:

62.9~86.0 lb-ft (85.3~116.7 N•m, 8.7~11.9 kg-m)




AV2A10B049

6. Install No.1 engine mounting.


Tightening torque:

49.1~68.7 lb-ft (66.7~93.1 N•m, 6.8~9.5 kg-m)



AV2A10B048

7. Set auto transaxle, engine and subframe on suitable floor jack and then place under vehicle.
8. Raise auto transaxle, engine and subframe and then align with engine compartment.




AV2A10026

9. Install four subframe nuts and four tension rod nuts.

Tightening torque:

Subframe: 88.2~101.2 lb-ft (119.6~137.3 N•m, 12.2~14.0 kg-m)

Tension rod: 68.7~84.6 lb-ft (93.1~114.7 N•m, 9.5~11.7 kg-m)




AV2A42123

10. Install No.3 engine mounting.

Tightening torque:

A: 62.9~86.0 lb-ft (85.3~116.7 N•m, 8.7~11.9 kg-m)

B: 49.1~68.7 lb-ft (66.7~93.1 N•m, 6.8~9.5 kg-m)




AV2A10B039A

11. Install No.4 engine mounting.

Tightening torque:

A: 62.9~86.0 lb-ft (85.3~116.7 N•m, 8.7~11.9 kg-m)


B: 49.1~68.7 lb-ft (66.7~93.1 N•m, 6.8~9.5 kg-m)



AV2A42119

12. Remove suitable floor jack from auto transaxle and engine.

13. Install A/C hose bracket bolt to subframe.



AV2A10B047

14. Install intermediate shaft bolt.

15. Remove suitable tool.


16. Install new clips on driveshaft.

17. Push driveshaft and joint shaft into transaxle with opening of clips pointing upward.

18. Install joint shaft support bracket and then install three bolts.

Tightening torque:

31.1~45.5 lb-ft (42.1~61.8 N•m, 4.3~6.3 kg-m)




BSX042461

19. Install both right and left lower arm ball joint into spindle and then install pinch bolts.

Tightening torque:

68.7~84.6 lb-ft (93.1~114.7 N•m, 9.5~11.7 kg-m)



AV2A42124

20. Install both right and left control links.

Tightening torque:

68.7~84.6 lb-ft (93.1~114.7 N•m, 9.5~11.7 kg-m)

21. Install both right and left tie rod ends to steering knuckle then install tie rod end nuts.

Tightening torque:

43.3~58.5 lb-ft (58.8~79.4 N•m, 6.0~8.1 kg-m)

22. Insert cotter pin and then bend over.

23. Install exhaust manifold.

24. Install A/C compressor.

25. Connect magnetic clutch connector.

26. Install drive belt.


27. Install both right and left wheels then tighten both right and left lug nuts.

Tightening torque:

65~87 lb-ft (88~118 N•m, 9~12 kg-m)


28. Slide ATF inlet and outlet hose onto ATF cooler pipe until it is fully seated against ridge.

29. Install hose clamp onto hose at center of mark and at angle shown.



AV2A42120

30. Install heater hose.



AV2A10B046

31. Install fuel hose from the fuel filter.

32. Install power steering fluid pipe to power steering pump.

33. Install two hose to power steering reserve tank.

34. Install brake vacuum hose to alternator.

35. Install auto transaxle filter tube assembly.


36. Connect two vacuum hoses and water temperature sensor connector.

37. Connect heater hose to thermostat housing.

38. Install nut and washer to auto transaxle linkage.


39. Install U-clip.

40. Connect five connector.



AV2A10B043

41. Install ground to body side.
42. Connect two ground connectors to fuse box.



43. Connect coolant reservoir hose to thermostat housing.
44. Connect RH side wiper motor connector.
45. Install flash air duct, air cleaner assembly and air cleaner bracket.
46. Install battery try and battery.
47. Connect negative and positive battery cable.
48. Fill transaxle with ATF.
49. Fill engine coolant with specified type and amount.
50. Fill power steering fluid.
51. Adjust auto transaxle control cable.
52. Start engine and then check for leaks.

DISASSEMBLY, INSPECTION AND REASSEMBLY PROCEDURE


* Notice

- Code all identical parts (such as pistons, piston rings, connecting rods, and valve springs) so that they can be reinstalled in the cylinder from which they were removed.
- Clean the parts with steam, blow off any remaining water with compressed air.
- Care should be taken during the disassembly of any part or system to study its order of assembly. Any deformation, wear or damage should also be noted.


Auxiliary parts

Disassembly


- Remove inter cooler cover.
- Remove inter cooler and inter cooler air inlet hose.




- Remove engine harness.
- Remove ventilator hose.
- Remove fuel injection pipe.




- Remove air separator and air separator hose/pipe.



- Remove ventilation pipe and hose.
- Remove lower water hose from cylinder block.
- Remove EGR pipe.
- Remove alternator, hose, alternator bracket and auto tensioner.




- Remove thermostat housing assembly.




- Remove turbo charger insulator.

13. Remove turbo charger assembly.



AV2A10B058A

14. Remove water bypass hose and water bypass pipe.




AV2A10B059

15. Remove power steering pump bracket.

16. Remove exhaust manifold insulator, exhaust manifold and gasket.


17. Remove EGR valve and gasket.

18. Remove intake manifold and gasket.




EFL0FL052

19. Remove common rail.




EFL0FL017

20. Install **SST (0K410 101 004)** to engine.



AV2A10B037

21. Mount engine on the **SST (0K130 990 007)**.



AV2A10B060

Reassembly

Assembly will be performed in the reverse order.

Timing belt cover

Disassembly

1. Remove No.3 engine mounting bracket.
2. Remove water pump pulley.
3. Remove power steering pump.
4. Remove crankshaft pulley.
5. Remove idler and bracket.
6. Remove upper timing belt cover.
7. Remove lower timing belt cover.

Reassembly

1. Install upper and lower timing belt cover.

Tightening torque:

5.1~7.2 lb-ft (6.9~9.8 N•m, 0.7~1.0 kg-m)

2. Install idler and bracket.

Tightening torque:

27.5~38.3 lb-ft (37.2~51.9 N•m, 3.8~5.3 kg-m)

3. Install crankshaft pulley.

Tightening torque:

253~289 lb-ft (343~392 N•m, 35~40 kg-m)

4. Install power steering pump.

Tightening torque:


21.7~28.9 lb-ft (29.4~39.2 N•m, 3.0~4.0 kg-m)

5. Install No.3 engine mounting bracket.

Tightening torque:

49.2~68.7 lb-ft (66.6~93.1 N•m, 6.8~9.5 kg-m)

Timing belt




AV2A10B062A


- | | |
|--------------------------|--------------------------------|
| (1) Timing belt | (9) Injector bracket |
| (2) Water pump | (10) Injector |
| (3) Camshaft pulley | (11) Cylinder head cover |
| (4) Tensioner | (12) Rocker arm shaft assembly |
| (5) Idler | (13) Camshaft cap |
| (6) Timing belt pulley | (14) Camshaft |
| (7) Upper plate assembly | (15) Cylinder head |
| (8) Engine hanger | |

Disassembly

1. Rotate crankshaft and align timing mark on timing belt pulley with timing mark on engine block.




2. Remove the auto tensioner.
3. Remove the timing belt.
4. Remove the high pressure pump.
5. Install the **SST (0K552 111 001)** as shown in the figure and then remove the camshaft pulley.



6. Remove the idler.
7. Remove the timing belt pulley.
8. Remove the upper plate assembly.
9. Remove the engine hanger.
10. Remove the injector bracket and injector.
11. Remove the cylinder head cover.
12. Remove the rocker arm shaft assembly.
13. Remove the camshaft cap and camshaft.

14. Remove the cylinder head bolts in the order shown in the figure.




Inspection

Front timing belt

*** Notice**


- a) Never forcefully twist, turn inside out or bend timing belt.
- b) Do not allow oil or grease to come in contact with timing belt.

1. Replace timing belt if it is contaminated with oil or grease.
2. Check timing belt for uneven wear, fraying, peeling, cracking and hardening. Replace timing belt if necessary.



ABT010217

3. Bend timing belt into a "U" shapes as shown in figure. Distance "A" must be at least 1.0 in (25 mm).



ABT010216

Camshaft pulleys and timing belt pulley


*** Notice**

Do not clean pulleys with cleaning fluids. If needed, use a soft cloth to wipe them clean, and avoid scratching the pulleys as it will affect integrity of the timing belt.

1. Check pulley teeth for wear, deformities and other damage. Replace pulleys if necessary.

Tensioner spring

1. Check the tensioner spring. Replace tensioner spring if necessary.




AV2A10B083

Tensioner and idler

*** Notice**

Do not clean tensioner pulley or idler pulley with cleaning fluids. If needed, use a soft rag to wipe them clean. Avoid scratching tensioner pulley or idler pulley as it can affect integrity of timing belt.

1. Check tensioner pulley and idler pulley for smooth rotation and proper sound. Replace tensioner pulley and idler pulley if necessary.




AV2A10B064

Camshaft

1. Set front and rear camshaft bearing journals on V-blocks.
2. Position a dial indicator on center bearing journal and zero dial.
3. Rotate camshaft in V-blocks and check runout.

Runout: 0.0031 in (0.08 mm) maximum




AV2A10B066

4. Check camshaft for uneven wear patterns, cracks, or damage.
5. Measure cam lobe heights at two points as shown.

Lobe height

Intake : 0.8857 in (22.497 mm)

Exhaust : 0.8894 in (22.593 mm)




AV2A10B067

6. Check camshaft bearing journal diameter (X and Y directions) on both sides (A and B) of journal as shown in figure.

Minimum diameter:

1.1000~1.1032 in (27.941~27.960 mm)




BSX010B089A

7. Replace camshafts if necessary.
8. Measure camshaft journal oil clearance.
9. Remove all foreign material and oil from journals and bearing surfaces.
10. Set camshafts onto cylinder head.
11. Position plastigage® on journals in axial direction.
12. Do not rotate camshafts.
13. Install camshaft caps according to cap number and arrow mark.
14. Install cap nuts. Tighten them in five or six steps in order shown.


Tightening torque:

13.0~19.5 lb-ft (17.6~26.5 N·m, 1.8~2.7 kg-m)



AS2A10107

15. Loosen camshaft cap nuts in five or six steps in order shown.
16. Remove camshaft caps.




AS2A10107

17. Measure oil clearances.

Oil clearance:

0.0016~0.0031 in (0.04~0.08 mm)

18. If oil clearance exceeds specification, replace cylinder head.




BSX010B093

19. Install camshafts.
20. Place a dial indicator against end of camshaft.
21. Using a prying tool, move camshaft as far forward as possible.
22. Zero dial.
23. Using prying tool, move camshaft as far rearward as possible.
24. Check gauge to determine how much end play is present.

End play:

0.0031~0.0046 in (0.08~0.11 mm)



BSX010B094

Rocker arm and rocker arm shaft

1. Measure the rocker arm inner diameter.

Inner diameter:

0.7862~0.7874 in (19.97~20.00 mm)

2. Measure the rocker arm shaft outer diameter.

Outer diameter:

0.7875~0.7886 in (19.959~19.980 mm)

Reassembly

1. Remove all foreign material from the top of the cylinder block.
2. Place the new cylinder head gasket in position.

Caution

Measure the length of cylinder head bolt, replace if necessary.

Long bolt: 5.2 in (132 mm)

Short bolt: 3.7 in (93 mm)


3. Install the cylinder head.
4. Apply an engine oil into the surface and thread of cylinder head bolt, and install the cylinder head bolts to the cylinder head.
5. Tighten the cylinder head bolts in the order shown in the figure.

Tightening torque:

Angle control



Long bolt: 25.32 lb-ft (34.3 N•m, 3.5 kg-m)+45°+70°

Short bolt: 25.32 lb-ft (34.3 N•m, 3.5 kg-m)
+40°+45°



AV2A10B008

6. Remove all foreign material and oil from the journals and bearing surface.
7. Set the camshaft onto the cylinder head.
8. Install the camshaft caps according to the cap number and arrow mark.




AV2A10B065

9. Install the camshaft cap nuts and tighten them in two or three steps in the order shown in the figure.

Tightening torque:

13.0~19.5 lb-ft (17.6~26.5 N•m, 1.8~2.7 kg-m)



AS2A10107

* Notice

Do not exchange intake rocker arm shaft and exhaust rocker arm shaft each other.


• Intake side: Yellow

• Exhaust side: Black

10. Install the intake rocker arm shaft and exhaust rocker arm shaft and tighten them in two or three steps in the order shown in the figure.

Tightening torque:

13.0~19.5 lb-ft (17.6~26.5 N•m, 1.8~2.7 kg-m)



AV2A10B025

11. Install the cylinder head cover.


Tightening torque:

5.1~6.5 lb-ft (6.9~8.8 N•m, 70~90 kg-cm)



Inspect clearance between dowel pin of camshaft end and phase sensor, before install cylinder head cover.

Clearance: 0.019~0.059in (0.5~1.5mm)



12. Install the injector and install the injector bracket.

Tightening torque:

14.5~15.9 lb-ft (19.6~21.6 N•m, 2.0~2.2 kg-m)

13. Install the front and rear engine hanger.

14. Install the upper plate assembly.

15. Install the idlers.

Tightening torque :

29.7lb-ft (40.2N•m , 4.1kg-m)



*Be careful that the idlers does not change.
Idler No.1(\varnothing 2.36in(\varnothing 60mm)), Idler No.2(\varnothing 2.16in
(\varnothing 55mm))*


16. Install the high pressure pump.

- 1) Tighten the high pressure pump assembly fixing bolts after installed the high pressure pump to the timing case.

Tightening torque :

15.9~18.8lb-ft (21.6~25.5N•m , 2.2~2.6kg-m)

- 2) Pre-tighten the high pressure pump pulley lock nut after installed the high pressure pump pulley to the high pressure pump shaft with key.
- 3) Fix the high pressure pump pulley by used to two setting bolts, after aligned the high pressure pump pulley timing mark as shown illust.



- 4) Tighten the high pressure pump pulley lock nut.

Tightening torque :

47.0lb-ft (63.7N•m , 6.5kg-m)

- 5) Install the high pressure pump bracket to the high pressure pump and cylinder block.

Caution

First tighten the cylinder block side bolts and then second tighten the pump side bolts after checking that there is no clearance between bracket and pump.


Tightening torque :

Pump side :

15.9~18.8lb-ft (21.6~25.5N•m , 2.2~2.6kg-m)

Cylinder block side :

25.3~29.7lb-ft (34.3~40.2N•m , 3.5~4.1kg-m)



EFL0FL061

17. Align the crankshaft pulley timing mark.


Caution

When the crankshaft is rotated without timing belt, could damage piston and valve. Before assemble the cylinder head, align TDC for No.1 piston.

18. Align the camshaft pulley timing mark.

- 1) Align "EX" mark of the left camshaft pulley and "IN" mark of the right camshaft pulley to the cylinder head top face as shown illust

Caution



BV2A10B003

When the camshaft is rotated without timing belt, could damage piston and valve. Before assemble the cylinder head, align the camshaft pulley timing mark

- 2) Install the camshaft fixing tool (SST) between two camshaft pulleys.
- 3) Tighten the camshaft pulley lock nut.

Tightening torque :

47.0lb-ft (63.7N•m , 6.5kg-m)

- 4) Remove the camshaft fixing tool (SST).

19. Install the timing belt.


- 1) The timing belt is installed in sequence crank shaft pulley, idler No.2, high pressure pump pulley, idler No.1 and camshaft pulley.

* Notice

- a) The auto-tensioner must be mounted onto the engine after the timing belt is installed.
- b) Keep the tension of timing belt when install timing belt.

20. Install the auto-tensioner.

- 1) Install the auto-tensioner as shown illust. The dowel pin has to be located between the tensioner fork (back plate).



BV2A10B004

- 2) Pretighten the auto-tensioner.

Tightening torque :

2.9lb-ft (3.9N•m , 0.4kg-m)

* Notice


- a) Oil must not get in contact with the tensioner. The tensioner has to be replaced by a new one, if it is oily.
- b) The positions of the pointer, the back plate and the special washer are in accordance to the illust.

21. Install the touch idler.

Tightening torque :


17.4lb-ft (23.5N•m , 2.4kg-m)

22. Remove two setting bolts from the high pressure pump pulley.
 23. Check again if the alignment marks of camshafts, crankshaft and high pressure pump are aligned with the marks on the timing case.



24. Adjust the auto-tensioner, and then tighten it.


- 1) Align the pointer to the back plate by rotating the special washer in counter-clockwise using the hexagon wrench as shown illust.



- 2) Tighten the auto-tensioner lock bolt with holding the special washer by the hexagon wrench when the pointer is aligned with the back plate.

Tightening torque :

17.4lb-ft (23.5N•m , 2.4kg-m)




- 3) Remove the hexagon wrench.

*** Notice**

If the pointer can not be aligned with the back plate, then a new belt has to be used.


25. Rotate the crankshaft two full revolutions in clockwise to align the TDC mark.
 26. Check again if the alignment marks of camshafts, crankshaft and high pressure pump are aligned with the marks on the timing case.
 27. Check the alignment of the pointer and back plate.



Allowance misalignment : $\pm 5^\circ$

28. If the misalignment between pointer and back plate is bigger than ($\pm 5^\circ$), repeat step 23~27.

Cylinder head




AV2A10B082

- | | |
|-----------------------------|-----------------------------|
| (1) Valve cotter | (4) Valve spring lower seat |
| (2) Valve spring upper seat | (5) Valve |
| (3) Valve spring | (6) Valve seal |

Disassembly


1. Remove the valve cotter by using the **SST (0K993 120 001 / 0K993 120 004)**.



AV2A10B068

2. Remove the valve spring upper seat, valve spring, valve spring lower seat and valve.

3. Pull the valve seal out by using the **SST (0K993 120 006)**.



AV2A10B069

Inspection


Valve mechanism

1. Inspect each valve for following:
 - a. Damaged or bent valve stem
 - b. Rough or damaged face
 - c. Damaged or unevenly worn stem tip
2. Resurface or replace valve as needed.

Margin thickness

Intake: 0.047 in (1.2 mm)

Exhaust: 0.043 in (1.1 mm)




BSX010A110

3. Measure diameter of each valve stem.

Diameter

Intake: 0.2742~0.2748 in (6.965~6.980 mm)

Exhaust: 0.2734~0.2740 in (6.945~6.960 mm)




BSX010A111

4. Measure inside diameter of each valve guide at points shown in figure.

Diameter intake and exhaust valve guide:

0.2759~0.2767 in (7.010~7.030 mm)




BSX010A112

Valve spring

1. Inspect each valve spring for cracks and damage.
2. Measure free length and out-of-square. Replace valve springs as needed.

Free length: 2.066 in (52.47 mm)


Out-of-square: 2° maximum



AS2A10139


Reassembly

1. By using the proper tool, press the valve seal.




AV2A10B070

2. Install the valve, valve spring lower seat, valve spring and valve spring upper seat.
3. By using **SST (0K993 120 001 / 0K993 120 004)**, compress the valve spring and place the valve cotter securely.
4. By using a plastic hammer, tap the stem lightly to assure proper fit.



AV2A10B068

Cylinder block



AV2A10B071

- | | |
|--|----------------------------|
| (1) Oil pan | (14) Connecting rod cap |
| (2) Oil feed pipe | (15) Connecting rod |
| (3) Timing belt case | (16) Main bearing |
| (4) Chain | (17) Piston and piston pin |
| (5) Ladder frame | (18) Piston rings |
| (6) Oil strainer | (19) Main bearing cap |
| (7) Lever | (20) Main bearing |
| (8) Oil pump | (21) Crankshaft |
| (9) Tensioner | (22) Balance gear |
| (10) Guide | (23) Thrust plate |
| (11) Clutch cover and clutch disc (MTX only) | (24) Balance shaft |
| (12) Flywheel (MTX only) | (25) Oil jet |
| (13) Rear cover | (26) Balance sprocket |

Disassembly

1. Remove the clutch cover, clutch disc and flywheel.
2. Remove the oil pan mounting bolts.
3. Remove oil pan with a screwdriver or suitable tool.


Caution

- a) **Do not force tools between cylinder block and oil pan as this may damage sealing surface.**
- b) **Do not damage sealing surface when removing old sealant.**

4. Remove the oil feed pipe.
5. Remove the timing belt case.
6. Loosen balance sprocket bolt.

* Notice

Insert the 0.2 in(5mm) urethane rubber between balance gear to prevent the balance shaft from rotating and the balance gear from damaging.




AV2A1B033

7. When disassembling the balance sprocket, hold the balance sprocket by one hand with pushing the thrust plate slightly then the balance separates from the neck of balance shaft.
8. Remove the chain.
9. Remove the ladder frame.
10. Remove the oil strainer and oil pump.
11. Remove the lever, tensioner and guide.
12. Remove the rear cover.

13. Before removing the connecting rod, measure the connecting rod side clearance.

Side clearance: 0.0055~0.0153 in (0.14~0.39 mm)




AN9010052

14. Remove connecting rod cap.
15. Measure the connecting rod bearing oil clearance.
 - 1) Remove all foreign material and oil from the crank pin and bearing surface.
 - 2) Position Plastigage atop the crank pin in the axial direction.
 - 3) Install the connecting rod cap and tighten.

Tightening torque:

**Tighten 50.6 lb-ft (68.6 N•m, 7.0 kg-m),
tighten 21.7 lb-ft (29.4 N•m, 3.0 kg-m) and
then tighten 90°.**



AN9010049


- 4) Loosen the connecting rod cap nuts.
- 5) Measure the oil clearance at each crank pin.

Oil clearance:

0.00169~0.00303 in (0.043~0.077 mm)

16. Remove the connecting rod and piston.
17. Before removing the main bearing cap, measure the crankshaft end play.

End play: 0.0055~0.0153 in (0.14~0.39 mm)




AN7010A165

18. Remove main bearing cap.
19. Measure the main bearing oil clearance
 - 1) Remove all foreign material and oil from the journals and bearing surface.
 - 2) Position Plastigage atop the journals in the axial direction.
 - 3) Install the main bearing cap and tighten as shown in the figure.

Tightening torque:

Pretighten 54.97 lb-ft (74.5 N•m, 7.6 kg-m), and then tighten 60°.




AN7010A164

- 4) Loosen the main bearing cap bolts and remove main bearing cap.
- 5) Measure the oil clearance at each journal.

Oil clearance:

No.1,2,4,5: 0.00177~0.00311 in (0.045~0.079 mm)
No.3: 0.00267~0.00397 in (0.068~0.101 mm)

20. Loosen the main bearing cap bolts in two or three steps in the order shown in the figure.
21. Remove the main bearing cap, main bearing and crankshaft.



AV2A10B072


22. Remove the balance shaft and thrust plate.
23. Remove the balance gear.
24. Remove the oil jet.
25. Remove the snap ring with snap ring pliers and then remove the piston pin.
26. Using a piston ring expander, remove piston rings.

Inspection

Ladder frame and balance shaft

1. Measure outer diameter of balance shaft and inner diameter of ladder frame. Replace if necessary.

| Inner diameter of ladder frame (mm) | | Outer diameter of balance shaft (mm) | |
|--|--|---|--|
| LH1 | 0.9843~0.9851 in (25.000~25.021 mm) | LH1 | 0.9818~0.9827 in (24.939~24.960 mm) |
| LH2 | 2.1259~2.1272 in (54.000~54.030 mm) | LH2 | 2.1224~2.1236 in (53.910~53.940 mm) |
| LH3 | 2.2047~2.2059 in (56.000~56.030 mm) | LH3 | 2.2012~2.2023 in (55.910~55.940 mm) |
| RH1 | 1.3779~1.3789 in (35.000~35.025 mm) | RH1 | 1.3749~1.3759 in (34.925~34.950 mm) |
| RH2 | 2.1259~2.1272 in (54.000~54.030 mm) | RH2 | 2.1224~2.1236 in (53.910~53.940 mm) |
| RH3 | 2.2047~2.2059 in (56.000~56.030 mm) | RH3 | 2.2012~2.2023 in (55.910~55.940 mm) |




AV2A10B026

Piston

- * Notice
Replacing a piston also requires replacing piston rings.

1. Check circumference of piston for damage, scoring, or unusual wear patterns. Replace piston as needed.




AV2A10B073

2. Check outside diameter of each piston at a 90° right angle to piston pin, 0.16 in (15 mm) above lower end of piston.

Piston diameter
A gread: 3.8195~3.8201 in (97.015~97.030 mm)
B gread: 3.8201~3.8207 in (97.030~97.045 mm)

- * Notice
If piston is collapsed or bell mounthed, replace piston.




AV2A10B074

3. Check piston-to-cylinder liner wall clearance by subtracting piston diameter from the largest cylinder liner wall diameter, at each cylinder.

Clearance: 0.0028~0.0039 in (0.070~0.098 mm)

4. If clearance exceeds maximum, replace piston or cylinder liner.



AS2A10080

Piston rings

1. Insert a new piston ring into a piston ring groove and check piston ring-to-side clearance. Piston ring groove clearance.


Piston ring groove clearance:

Top ring: 0.0029~0.0040 in (0.076~0.102 mm)

Second ring: 0.0016~0.0031 in (0.040~0.080 mm)


Oil ring: 0.0012~0.0028 in (0.030~0.070 mm)

Limit: 0.0118 in (0.30 mm)



AS2A10081

2. If clearance exceeds the limit, replace piston.
3. Inspect piston rings for damage, abnormal wear, or breakage.
4. Replace piston rings if necessary.
5. Insert piston ring into cylinder by hand.
6. Square ring in cylinder by inverting a piston into cylinder and pushing ring to the bottom of its travel in cylinder liner.



AS2A10081

7. Place a feeler gauge in end gap and check end gap clearance.


End gap clearance:

Top ring: 0.0118~0.0177 in (0.30~0.45 mm)

Second ring: 0.0157~0.0217 in (0.40~0.55 mm)

Oil rail: 0.0079~0.0157 in (0.20~0.40 mm)

Limit: 0.0591 in (1.50 mm)




ABT010208

8. Replace piston ring if necessary.

Piston pin

1. Measure each piston pin diameter at X and Y direction at four locations shown.

Diameter: 1.2596~1.2598 in (31.994~32.000 mm)




AS2A10142

Connecting rod

1. Check connecting rod bushing inside diameter.

Inside diameter:
1.2603~1.2611 in (32.012~32.033 mm)




AS2A10143A

2. Subtract piston pin diameter from connecting rod bushing inside diameter to determine piston pin fit.

Clearance: 0.0005~0.0015 in (0.012~0.039 mm)

3. If clearance is not within specification, replace connecting rod bushing.
4. Check each connecting rod for bending.



ABT010210

5. Replace connecting rods if necessary.


*** Notice**

Connecting rods must always be replaced as an assembly. Rod cap, rod, bolts and nuts are a matched set.

Crankshaft

1. Check crankshaft bearing and crank pin journals for damage and scoring.
2. Check oil holes for clogging.
3. Set crankshaft on V-blocks.
4. Measure crankshaft run-out at center journal. Replace crankshaft if it is not within specification.

Run-out: 0.0055~0.0154 in (0.14~0.39 mm)



AV2A10B075

Pin journal bearing selection

1. Check the connecting rod big-end bore size code.

* **Notice**

The code is carved on connecting rod cap bolt hole side.

Connecting rod big-end bore diameter

| Grade | Connecting rod big-end bore diameter |
|-------|---------------------------------------|
| 1 | 2.39499~2.39523 in (60.833~60.839 mm) |
| 2 | 2.39523~2.39550 in (60.839~60.846 mm) |

Crankshaft pin journal diameter:
2.24827~2.24898 in (57.106~57.124 mm)

2. Choose the proper pin journal bearing as below table.

Pin journal bearing clearance:
0.00138~0.00272 in (0.035~0.069 mm)

Pin journal bearing selection table

| Connecting rod grade | Pin journal bearing grade | Oil clearance |
|----------------------|---------------------------|-------------------------------------|
| 1 | Blue | 0.00146~0.00272 in (0.037~0.069 mm) |
| 2 | Red | 0.00138~0.00268 in (0.035~0.068 mm) |

* **Notice**

Painting mark is located on the bearing side face.

Pin journal bearing thickness

| Color | Pin journal bearing thickness |
|-------|-------------------------------------|
| Blue | 0.07213~0.07228 in (1.832~1.836 mm) |
| Red | 0.07228~0.07244 in (1.836~1.840 mm) |

3. Position properly upper bearing and lower bearing to connecting rod and connecting rod cap and then install connecting rod and connecting rod cap to crankshaft pin journal

Tightening torque:
Tighten 50.6 lb-ft (68.6 N•m, 7.0 kg-m),
tighten 21.7 lb-ft (29.4 N•m, 3.0 kg-m) and
then tighten 90°.

Main journal bearing selection

1. Check the cylinder block main bearing bore size code.

* **Notice**

The code is located on the side of ladder frame bolt hole.

Cylinder block main bearing bore diameter

| Code | Cylinder block main bearing bore diameter |
|------|---|
| A | 2.91598~2.91633 in (74.066~74.075 mm) |
| • | 2.91633~2.91669 in (74.075~74.084 mm) |
| C | 2.91669~2.91700 in (74.084~74.092 mm) |

2. Check the crankshaft main journal size code.

* **Notice**

The code is located on the between main journal and pin journal.

Crankshaft main journal diameter

| Code | Crankshaft main journal diameter | |
|------|---------------------------------------|---------------------------------------|
| | No. 1, 2, 4, 5 | No. 3 |
| A | 2.75570~2.75598 in (69.995~70.002 mm) | 2.75483~2.75511 in (69.973~69.980 mm) |
| • | 2.75598~2.75625 in (70.002~70.009 mm) | 2.75511~2.75539 in (69.980~69.987 mm) |
| C | 2.75625~2.75649 in (70.009~70.015 mm) | 2.75539~2.75562 in (69.987~69.993 mm) |

3. Choose the proper main journal bearing in below table.

Main journal bearing selection table

| | | Cylinder block main bearing bore size code | | |
|-----------------------------------|---|--|-------|-------|
| | | A | • | C |
| Crankshaft main journal size code | A | Brown | Black | Black |
| | • | Green | Brown | Black |
| | C | Yellow | Green | Brown |

Main journal bearing clearance:
No.1,2,4,5: 0.00146~0.00280 in (0.037~0.071 mm)
No.3: 0.00232~0.00366 in (0.059~0.093 mm)

Main journal bearing thickness

| Color | Main journal bearing thickness |
|--------|-------------------------------------|
| Black | 0.07925~0.07945 in (2.013~2.018 mm) |
| Brown | 0.07905~0.07925 in (2.008~2.013 mm) |
| Green | 0.07886~0.07905 in (2.003~2.008 mm) |
| Yellow | 0.07866~0.07886 in (1.998~2.003 mm) |

- Position properly upper bearing and lower bearing to cylinder block and main bearing cap.
- Set crankshaft to cylinder block and then install main bearing cap to cylinder block.

Tightening torque:

Pretighten 54.97 lb-ft (74.5 N·m, 7.6 kg-m), and then tighten 60°.

Cylinder liner and piston selection

- Check the cylinder bore inner diameter size code of cylinder block.

**Notice**

The code is carved on the top of each cylinder.

Cylinder bore inner diameter

| Code | Cylinder bore inner diameter |
|------|---------------------------------------|
| Y | 3.9966~3.9971 in (101.513~101.526 mm) |
| X | 3.9960~3.9966 in (101.500~101.513 mm) |

- Choose the proper cylinder liner as below table.

Clearance between cylinder liner and cylinder bore of cylinder block :

0.0003~0.0013 in (0.007~0.033 mm)

Cylinder liner selection table

| Cylinder bore size code | Cylinder liner mark | Oil clearance |
|-------------------------|---------------------|-----------------------------------|
| Y | 3Y - Yellow | 0.0003~0.0013 in (0.007~0.033 mm) |
| Y | 3Y - Blue | 0.0003~0.0013 in (0.007~0.033 mm) |
| X | 3X - Yellow | 0.0003~0.0013 in (0.007~0.033 mm) |
| X | 3X - Blue | 0.0003~0.0013 in (0.007~0.033 mm) |

Piston selection table

| Cylinder liner mark | Piston mark | Oil clearance |
|---------------------|-------------|-----------------------------------|
| Yellow | B | 0.0028~0.0039 in (0.070~0.098 mm) |
| Blue | A | 0.0028~0.0039 in (0.070~0.098 mm) |

**Notice**

The mark for outer diameter is carved on the out surface of liner and for inner diameter is painted on the top of liner.

Cylinder liner outer diameter and inner diameter

| Code | Outer diameter | Color | Inner diameter |
|------|---------------------------------------|--------|-------------------------------------|
| 3Y | 3.9958~3.9963 in (101.493~101.506 mm) | Yellow | 3.8234~3.8239 in (97.115~97.128 mm) |
| 3Y | 3.9958~3.9963 in (101.493~101.506 mm) | Blue | 3.8228~3.8233 in (97.100~97.113 mm) |
| 3X | 3.9953~3.9958 in (101.480~101.493 mm) | Yellow | 3.8234~3.8239 in (97.115~97.128 mm) |
| 3X | 3.9953~3.9958 in (101.480~101.493 mm) | Blue | 3.8228~3.8233 in (97.100~97.113 mm) |

Piston outer diameter

| Code | Piston outer diameter |
|------|-------------------------------------|
| A | 3.8195~3.8201 in (97.015~97.030 mm) |
| B | 3.8201~3.8207 in (97.030~97.045 mm) |

Reassembly


* **Notice**

- a) Clean all parts before reassembly.
- b) Apply new engine oil to all sliding and rotating parts.

1. Install the three-piece oil rings on the pistons.
 - 1) Apply engine oil to the oil ring spacer and rails.
 - 2) Install the oil ring spacer so that the opening faces upward.
 - 3) Install the upper rail and lower rail.


* **Notice**

- a) The upper rail and lower rail are the same.
- b) Each rail can be installed with either face upward.



AS2A10085

2. Check that both rails are expanded by the spacer tangs as shown in figure by checking that both rails turn smoothly in both directions.




ABT010170

3. Install the second ring to the piston first, then install the top ring. Use piston ring expander.


* **Notice**

The rings must be installed with the "Y" marks facing upward.



AV2A10B076

4. Apply a liberal amount of clean engine oil to the second and top piston rings.
5. Position the opening of each ring as shown in the figure.




BSX010A162

6. Install one piston pin snap ring into grooves on piston.
7. Insert connecting rod into piston and slide piston pin through piston and through connecting rod until it makes contact with the piston pin snap ring already installed.


* **Notice**

Verify that piston and rod are assembled in same direction as they were prior to disassembly.



AS2A10096

8. Install second piston pin snap ring grooves on opposite side of piston.



AS2A10097

9. Hold piston upright and move connecting rod back and forth. Check that rod moves freely.
 10. Install the oil jet.
 11. Before installing the crankshaft, inspect the main bearing oil clearance as follows.

Oil clearance inspection

- (1) Remove all foreign material and oil from the journals and bearings.

Caution


- a) **Install the grooved upper main bearings in the cylinder block.**
 b) **Install the thrust bearings with the oil groove facing the crankshaft.**

- (2) Install the upper main bearings and thrust bearings.
 (3) Set the crankshaft in the cylinder block.

Caution

Do not rotate the crankshaft when measuring the oil clearances.

- (4) Position plastigage atop the journals in the axial direction.




AV2A10B079

- (5) Install the lower main bearings and the main bearing caps according to the cap number and \Leftarrow mark.
 (6) Tighten the main bearing cap bolts in two or three steps in the order shown in the figure.

Tightening torque:

Pretighten: 54.97 lb-ft (74.5 N·m, 7.6 kg-m) and then tighten 60°



AV2A10B072

- (7) Remove the main bearing caps, and measure the plastigage at each journal at the widest point for the smallest clearance and at the narrowest point for the largest clearance.
 (8) If the oil clearance exceeds specification, grind the crankshaft and use undersize main bearings.


Oil clearance:

**No.1,2,4,5: 0.00146~0.00280 in (0.037~0.071 mm)
 No.3: 0.00232~0.00366 in (0.059~0.093 mm)**

12. Apply a liberal amount of clean engine oil to the main bearings, thrust bearings and main journals.
13. Install the crankshaft and the main bearing caps according to the cap number and ↵ mark.
14. Tighten the main bearing cap bolts in two or three steps in the order shown in the figure.

Tightening torque:

Pretighten: 54.97 lb-ft (74.5 N•m, 7.6 kg-m) and then tighten 60°.



AV2A10B072

15. Before installing the connecting rod, inspect the connecting rod bearing oil clearance as follows.
 - (1) Slip piston and connecting rod assembly into a piston ring compressor.
 - (2) Rotate crankshaft so that crank pin journal for specific cylinder is at its lowest point (bottom dead center).
 - (3) Lower piston and connecting rod assembly until piston ring compressor makes contact with deck surface of engine block.



BSX010B103

- (4) Using butt end of a hammer, tap the top of piston into cylinder and continue tapping until connecting rod makes contact with crankshaft.
- (5) Install a connecting rod bearing in each connecting rod cap.
- (6) Place a piece of Plastigage® on crank pin journals.


*** Notice**

Align the machining marks on the cap and connecting rod when installing the connecting rod cap.

- (7) Install connecting rod caps.

Tightening torque:

Tighten 50.6 lb-ft (68.6 N•m, 7.0 kg-m), tighten 21.7 lb-ft (29.4 N•m, 3.0 kg-m) and then tighten 90°



AV2A10B080

- (8) Loosen and remove connecting rod caps.
- (9) Check the connecting rod bearing clearance.

Oil clearance:

0.00138~0.00272 in (0.035~0.069 mm)

- (10) If oil clearance exceeds maximum oil clearance specification, grind the crankshaft and use undersized connecting rod bearings.
- (11) Apply a coat of clean engine oil to connecting rod bearing in connecting rod cap.
- (12) Install connecting rod cap and torque to specification.

Tightening torque:

Tighten 50.6 lb-ft (68.6 N•m, 7.0 kg-m), tighten 21.7 lb-ft (29.4 N•m, 3.0 kg-m) and then tighten 90°

16. Install the balance shaft gear and thrust plate to the balance shaft.


Tightening torque:

32.5 lb-ft (44.1 N•m, 4.5 kg-m)

17. Install the balance shaft and thrust plate assembly into the ladder frame.

*** Notice**


- To prevent the balance shaft from being falled out, tighten the 1 of 3 balance gear cover bolts by hand into the thrust plate center.
- Align the maching marks on the balance gear and balance gear.



18. Install the ladder frame into block.
Check the dowel pin of ladder frame is matched with lower surface of block and insert the oil level gauge into the ladder frame hole.

Tightening torque (ladder frame bolt):

32.5 lb-ft (44.1 N•m, 4.5 kg-m)



19. Install the oil pump and oil strainer.
20. Install the oil feeding pipe into the ladder frame, oil pump and block, and then tighten bolts.

Tightening torque (oil feeding pipe bolt):

16.6 lb-ft (23 N•m, 2.3 kg-m)

21. Install the crankshaft sprocket, oil pump sprocket, chain guide and chain tensioner.

Tightening torque:

Chain guide: 6.5~9.4 lb-ft

(8.8~12.7 N•m, 0.9~1.3 kg-m)


Chain tensioner: 13.7~18.8 lb-ft

(18.6~25.5 N•m, 1.9~2.6 kg-m)


22. Adjust the crank shaft sprocket TDC mark and balance shaft sprocket timing mark with chain link mark(two yellow link), and then insert the balance sprocket into the neck of balance shaft.

*** Notice**

For smooth operation, pull the thrust plate out and hold, and then push the sprocket into the balance shaft.



23. Push the end of chain tensioner plunger utmost and then install the chain tensioner lever between chain and chain tensioner.



Tightening torque (chain tensioner lever):

6.5~9.4 lb-ft (8.8~12.7 N•m, 0.9~1.3 kg-m)

24. Tighten balance sprocket bolt.

*** Notice**

Insert the 0.2in (5mm) urethane rubber between balance gear to prevent the balance shaft from rotating and the balance gear from damaging.

Tightening torque:


Mark 10T: 50.6 lb-ft (68.6 N•m, 7 kg-m)

Mark 8T: 43.3 lb-ft (58.8 N•m, 6 kg-m)

25. Rotate the crankshaft sprocket 2 times and mark the chain 1 rotating fully, check the crankshaft sprocket TDC mark after checking the balance gear assembly mark. If not, readjustment is needed.

*** Notice**

The chain link mark position is only efficient to assembly, but it is not matched after 2 rotation of crank shaft sprocket. Timing check is only possible through the balance shaft gear.




AV2A10B081

26. Loosen the bolt on the thrust plate, and install the gear cover and tighten 3 bolts.

Tightening torque:

16.6 lb-ft (23 N•m, 2.3 kg-m)



AV2A10B035

27. Install the timing belt case.

28. Install the rear cover.

Tightening torque:


5.8~7.9 lb-ft (7.8~10.8 N•m, 80~110 kg-m)

29. Remove all foreign material from gasket surface.

*** Notice**

Install oil pan within five minutes of applying silicone sealer.

30. Apply a continuous bead of silicone sealant to oil pan contact surfaces.



31. Install the oil pan.

32. Install the flywheel, clutch disc and clutch cover.